



VN0601 ARINC 429 Interface Manual

Version 2.2 | English

Imprint

Vector Informatik GmbH
Ingersheimer Straße 24
D-70499 Stuttgart

The information and data given in this user manual can be changed without prior notice. No part of this manual may be reproduced in any form or by any means without the written permission of the publisher, regardless of which method or which instruments, electronic or mechanical, are used. All technical information, drafts, etc. are liable to law of copyright protection.

© Copyright 2023, Vector Informatik GmbH. All rights reserved.

Contents

1 Introduction	5
1.1 About this User Manual	6
1.1.1 Warranty	7
1.1.2 Registered Trademarks	7
1.2 Important Notes	8
2 VN0601 Network Interface	9
2.1 Introduction	10
2.2 Accessories	10
2.3 Examples of Usage	11
2.3.1 Analyzing Traffic of Multiple Lines	11
2.3.2 Transmitting and Monitoring	12
2.3.3 In-line Data Modification	13
2.4 Device Description	14
2.4.1 D-SUB37 Pin Assignment (ARINC 429)	14
2.4.2 D-SUB9 Pin Assignment (IO)	15
2.4.3 Synchronization	16
2.4.4 LEDs	17
2.4.5 Technical Data	18
3 Getting Started	19
3.1 Driver Installation	20
3.1.1 General Information	20
3.1.2 Installation Instructions	20
3.2 Vector Hardware Manager	22
3.2.1 Hardware Configuration	22
3.2.2 Tool Location and Help	22
4 Time Synchronization	23
4.1 General Information	24
4.2 Software Sync	26
4.2.1 General Information	26
4.2.2 Configuration	26
4.3 Hardware Sync	27
4.3.1 General Information	27
4.3.2 Configuration	28

5 Important Notes - Details	29
5.0.1 Safety Instructions and Hazard Warnings	30
5.0.2 Disclaimer	32
5.0.3 Disposal of Vector Hardware	33
6 Wichtige Hinweise	34
6.0.1 Sicherheits- und Gefahrenhinweise	35
6.0.2 Haftungsausschluss	37
6.0.3 Entsorgung von Vector Hardware	38

1 Introduction

In this chapter you find the following information:

1.1 About this User Manual	6
1.1.1 Warranty	7
1.1.2 Registered Trademarks	7
1.2 Important Notes	8

1.1 About this User Manual

Conventions

In the two following charts you will find the conventions used in the user manual regarding utilized spellings and symbols.

Style	Utilization
bold	Blocks, surface elements, window- and dialog names of the software. Accentuation of warnings and advices. [OK] Push buttons in brackets File Save Notation for menus and menu entries
Source Code	File name and source code.
Hyperlink	Hyperlinks and references.
<CTRL>+<S>	Notation for shortcuts.

Symbol	Utilization
	This symbol calls your attention to warnings.
	Here you can obtain supplemental information.
	Here you can find additional information.
	Here is an example that has been prepared for you.
	Step-by-step instructions provide assistance at these points.
	Instructions on editing files are found at these points.
	This symbol warns you not to edit the specified file.

1.1.1 Warranty

Restriction of warranty

We reserve the right to change the contents of the documentation and the software without notice. Vector Informatik GmbH assumes no liability for correct contents or damages which are resulted from the usage of the documentation. We are grateful for references to mistakes or for suggestions for improvement to be able to offer you even more efficient products in the future.

1.1.2 Registered Trademarks

Registered trademarks

All trademarks mentioned in this documentation and if necessary third party registered are absolutely subject to the conditions of each valid label right and the rights of particular registered proprietor. All trademarks, trade names or company names are or can be trademarks or registered trademarks of their particular proprietors. All rights which are not expressly allowed are reserved. If an explicit label of trademarks, which are used in this documentation, fails, should not mean that a name is free of third party rights.

- ▶ Windows, Windows 7, Windows 8.1, Windows 10, Windows 11 are trademarks of the Microsoft Corporation.

1.2 Important Notes

**Caution!**

We provide our important notes and safety instructions in several languages, including Englisch (EN) and German (DE). For more details, see the relevant section:

- ▶ EN: [Important Notes - Details](#)
- ▶ DE: [Wichtige Hinweise](#)

2 VN0601 Network Interface

In this chapter you find the following information:

2.1 Introduction	10
2.2 Accessories	10
2.3 Examples of Usage	11
2.3.1 Analyzing Traffic of Multiple Lines	11
2.3.2 Transmitting and Monitoring	12
2.3.3 In-line Data Modification	13
2.4 Device Description	14
2.4.1 D-SUB37 Pin Assignment (ARINC 429)	14
2.4.2 D-SUB9 Pin Assignment (IO)	15
2.4.3 Synchronization	16
2.4.4 LEDs	17
2.4.5 Technical Data	18

2.1 Introduction

General information

The VN0601 is a compact and powerful interface for ARINC 429 bus systems. The interface conveniently utilizes a PC connection via USB 2.0, it does not require an external power supply, and it has analog/digital interfaces for acquiring other measurement parameters. The VN0601 gives developers of networked electronic units in aircrafts (Line Replaceable Units or LRUs) a flexible and high-performance interface solution for testing and bus analysis.

Highlights

Main features of the VN0601 interface are:

- ▶ 4x ARINC 429 TX channel
- ▶ 4x ARINC 429 RX channel
- ▶ Support of high-speed and low-speed communication
- ▶ 1x analog Input
- ▶ 2x digital input
- ▶ 1x digital output
- ▶ Robust housing
- ▶ No external power supply required (USB-powered)

2.2 Accessories



Reference

Information on available accessories can be found in the separate accessories manual on our [website](#).

2.3 Examples of Usage

2.3.1 Analyzing Traffic of Multiple Lines

Description

The VN0601 can be used for traffic analyzing tasks. In this setup, the interface receives data simultaneously from two different ARINC lines, each having its own transmitting LRU. The lines are not influenced by the VN0601.

Setup




Figure 1: Analyzing traffic of multiple ARINC lines

2.3.2 Transmitting and Monitoring

Description

If no transmitting LRU is active or available, the missing TX LRU can be simulated with CANoe.A429 while the traffic can be monitored as usual.

Setup




Figure 2: Transmitting and monitoring

2.3.3 In-line Data Modification

Description

For testing purposes, certain RX LRUs can be disconnected from the TX LRU. In this remaining part of the line, the TX data is simulated in CANoe.A429.

Setup





Figure 3: In-line Data Modification

2.4 Device Description

2.4.1 D-SUB37 Pin Assignment (ARINC 429)

CH1...8

The VN0601 has a D-SUB37 connector (male) that provides up to eight ARINC 429 channels (four TX / four RX). The pin assignment is as follows:



TX channels

Pin	Assignment	Pin	Assignment
1	CH1 A	20	CH1 B
2	CH2 A	21	CH2 B
3	CH3 A	22	CH3 B
4	CH4 A	23	CH4 B
5	GND CH1...CH4	24...28	Reserved. Do not use.
6...9	Reserved. Do not use.		

RX channels

Pin	Assignment	Pin	Assignment
10	CH5 A	29	CH5 B
11	CH6 A	30	CH6 B
12	CH7 A	31	CH7 B
13	CH8 A	32	CH8 B
14	GND CH5...CH8	33...37	Reserved. Do not use.

2.4.2 D-SUB9 Pin Assignment (IO)


CH9

The VN0601 has a D-SUB9 connector (female) that provides digital and analog input/outputs.

Digital/analog IO

The pin assignment for CH9 is as follows:

Pin	Assignment
1	Analog input
2	Not connected
3	Not connected
4	Digital input 0
5	Digital input 1
6	Analog GND
7	Not connected
8	Digital output
9	Digital GND



Internal interconnection of digital input 0/1




Figure 4: Digital input 0/1

Internal interconnection of digital output




Figure 5: Digital output

Internal interconnection of analog input




Figure 6: Analog input

Extended measuring range of the analog input

In normal operation, voltages up to 18 V can be applied and measured at the analog input. The cutoff frequency f_c (-3 dB) for AC voltages is approx. 7.2 kHz.

For measurements above 18 V (max. 50 V), an external series resistor has to be applied to the analog input. The series resistor R_{ext} depends on the input voltage U_{input} and can be calculated as follows:

$$R_{ext} [k\Omega] = [(U_{input} * 0.61111) - 11] * 100$$

with $18 V < U_{input} \leq 50 V$

The cutoff frequency for AC voltages is also affected by the external series resistor:

$$f_c [Hz] = \frac{1}{2.33 * 10^{-6} * R_{ext} [k\Omega]}$$

Examples

	24 V	32 V	36 V	48 V
R_{ext}	367 k Ω	856 k Ω	1100 k Ω	1833 k Ω
R_{ext} (E96)	374 k Ω (24.12 V)	866 k Ω (32.17 V)	1100 k Ω (36.00 V)	1870 k Ω (48.60 V)
f_c (-3 dB)	1148 Hz	496 Hz	390 Hz	230 Hz

2.4.3 Synchronization

Sync connector

The VN0601 has a sync connector (Binder type 711) which can be used for time synchronization of different Vector devices (see section [Time Synchronization](#) on page 23). **The sync connector is not intended to connect a power supply.**

Pin	Assignment
1	Not connected
2	Synchronization line
3	Ground



2.4.4 LEDs

CH1 ... CH4 (Tx)

Color	Description
Green	 On: no traffic.  Flashing: data frames have been sent correctly.
Red	Transmit error.
Off	No running measurement.

CH5 ... CH8 (Rx)

Color	Description
Green	 On: no traffic.  Flashing: data frames have been received correctly.
Red	Receive error.
Off	No running measurement.

Status

Color	Description
Green	 On: running measurement.  Flashing: Device is ready for operation.
Orange	Initializing driver. Please wait.
Red	Error. Device not working.

2.4.5 Technical Data

ARINC 429 channels	4x TX 4x RX
Baud rates	Low-speed: 12 ... 14.5 kb/s High-speed: 100 kb/s
Transceiver	TX: Holt HI-8596 RX: Holt HI-8454
Analog input	10 bit Input 0 V...18 V Voltage tolerance up to 50 V (with series resistor) Sampling rate up to 1 kS/s
Digital input	Range 0 V...32 V Schmitt trigger high 2.7 V, low 2.2 V Hysteresis 0.5 V Input frequencies up to 1 kHz
Digital output	Open Drain External supply up to 32 V Output frequency up to 1 kHz Current max. 500 mA Short circuit / over voltage protected
Time stamps	Resolution: 15.625 ns Accuracy (in device): 1 µs Accuracy software sync: typ. 50 µs Accuracy hardware sync: typ. 1 µs
PC interface	USB 2.0
Power supply	USB
Power consumption	2.5 W
Temperature range (ambient temperature of the device)	Operation: -40 °C...+65 °C Storage: -40 °C...+85 °C
Relative humidity of ambient air	15 %...95 %, non-condensing
Weight	Approx. 250 g
Dimensions (LxWxH)	Approx. 91 mm x 109 mm x 35 mm
Operating system requirements	Windows 10 (x64, 64 bit)

3 Getting Started

In this chapter you find the following information:

3.1 Driver Installation	20
3.1.1 General Information	20
3.1.2 Installation Instructions	20
3.2 Vector Hardware Manager	22
3.2.1 Hardware Configuration	22
3.2.2 Tool Location and Help	22

3.1 Driver Installation

3.1.1 General Information

The **Vector Driver Setup** allows the installation or the removal of Vector devices.



Note

Please note that you will need **Administrator Rights** for the following steps.


3.1.2 Installation Instructions



Step by Step Procedure


1. Execute the driver setup `\Drivers\Setup.exe` before the device is connected to the PC with the included USB cable.

If you have already connected the device to the PC, the **Windows found new Hardware** wizard appears. Close this wizard and then execute the driver setup.



2. Click **[Next]** in the driver setup dialog. The initialization process starts.

3. In the driver selection dialog, select your devices to be installed (or to be uninstalled).




4. Click **[Install]** to execute the driver installation, or **[Uninstall]** to remove existing drivers.
5. A confirmation dialog appears. Click **[Close]** to exit. After successful installation, the device is ready for operation and can be connected to the PC with the included USB cable.

3.2 Vector Hardware Manager

3.2.1 Hardware Configuration

General information

The **Vector Hardware Manager** is the successor of the Vector Hardware Config tool and a newly developed configuration and diagnostic tool for your installed Vector devices. It is strongly needed to set up your Vector devices for use with your Vector applications (e. g. CANoe, CANalyzer, CANape, ...).



3.2.2 Tool Location and Help

After successful **driver installation** of your Vector device, you will find the Vector Hardware Manager in the Windows Start menu or in the installation folder:
`C:\Program Files (x86)\Vector Hardware Manager\vHardwareManager.exe`



Reference

Details, tips and instructions for the Vector Hardware Manager can be found in the supplied help. You can open the help by pressing **<F1>** in the Vector Hardware Manager or directly via:

`C:\Program Files (x86)\Vector Hardware Manager\Help01\HTML5\VectorHardwareManager.htm`

For a brief introduction, we recommend reading the sections **Basic Concept** and **Quick Start Guide**. Furthermore, we have provided additional information for you in the section **Tips and Tutorials**.

4 Time Synchronization


In this chapter you find the following information:

4.1 General Information	24
4.2 Software Sync	26
4.2.1 General Information	26
4.2.2 Configuration	26
4.3 Hardware Sync	27
4.3.1 General Information	27
4.3.2 Configuration	28

4.1 General Information

Time stamps and events

Time stamps are useful when analyzing incoming or outgoing data or event sequences on a specific bus.



Time	Chn	ID	Name	Dir	DLC	Data
0.100376	2	100		Rx	8	23 19 05 47 79 34 52 82
0.100378	1	100		Tx	8	23 19 05 47 79 34 52 82
0.200382	2	100		Rx	8	03 04 06 95 06 07 56 74
0.200384	1	100		Tx	8	03 04 06 95 06 07 56 74
0.300372	1	102		Rx	8	74 02 31 73 94 12 04 93
0.300374	2	102		Tx	8	74 02 31 73 94 12 04 93
0.400406	2	100		Rx	8	23 19 05 47 79 34 52 82
0.400408	1	100		Tx	8	23 19 05 47 79 34 52 82

Figure 7: Time stamps of two CAN channels in CANalyzer

Generating time stamps

Each event which is sent or received by a Vector network interface has an accurate time stamp. Time stamps are generated for each channel in the Vector network interface. The base for these time stamps is a common hardware clock in the device.




Figure 8: Common time stamp clock for each channel

If the measurement setup requires more than one Vector network interface, a synchronization of all connected interfaces and their hardware clocks is needed.

Due to manufacturing and temperature tolerances, the hardware clocks may vary in speed, so time stamps of various Vector devices drift over time.




Figure 9: Example of unsynchronized network interfaces. Independent time stamps drift apart

To compensate for these time stamp deviations between the Vector network interfaces, the time stamps can be either synchronized by software, hardware, PTP or GNSS (capability depends on the Vector device).



Note

The accuracy of the software, hardware, PTP or GNSS sync depends on the interface. Further information on specific values can be found in the technical data of the respective devices.

4.2 Software Sync

4.2.1 General Information

Synchronization by software

The software time synchronization is driver-based and available for all applications without any restrictions. The time stamp deviations from different Vector network interfaces are calculated and synchronized to the common PC clock. For this purpose no further hardware setup is required.




Figure 10: Time stamps of devices are synchronized to the PC clock



Note

Software time synchronization may lead to an increased latency for all connected Vector network interfaces. If a use case requires low latency, deactivate this option and use another synchronization mechanism.

4.2.2 Configuration

Vector Hardware Manager

Use the software synchronization if at least one device has no hardware sync connector. Also to synchronize the device clock to the computer time, use the software synchronization (legacy).



Reference

Further details and tips on the time sync configuration can be found in the Vector Hardware Manager help in section **User Interface | Navigation Rail | Time Sync**.

4.3 Hardware Sync

4.3.1 General Information

Synchronization by hardware

A more accurate time synchronization of multiple devices is provided by the hardware synchronization. Two Vector network interfaces can therefore be connected with the SYNCcableXL (see accessories manual, part number 05018).

In order to synchronize up to five devices at the same time, a distribution box is available (see accessories manual, part number 05085).




Figure 11: Example of a time synchronization with multiple devices




Figure 12: Example of a time synchronization with VN8914 and additional devices

At each falling edge on the sync line which is initiated by the driver, the Vector network interface generates a time stamp that is provided to the driver. This allows the driver to calculate the deviations between the network interfaces and to synchronize

the time stamps to a common time base (master clock) which can be defined by the user.




Figure 13: Time stamps are synchronized to the master clock

4.3.2 Configuration

Vector Hardware Manager

Use hardware synchronization if at least one device is connected with USB or PCIe to the PC and all devices are hardware sync capable. One device should be configured as master and all other devices as slaves. Therefore, all devices must be interconnected with SYNCcableXL and Multi SYNCbox external or SYNCbox active.



Reference

Further details and tips on the time sync configuration can be found in the Vector Hardware Manager help in section **User Interface | Navigation Rail | Time Sync**.

5 Important Notes - Details

In this chapter you find the following information:

5.0.1 Safety Instructions and Hazard Warnings	30
5.0.2 Disclaimer	32
5.0.3 Disposal of Vector Hardware	33

5.0.1 Safety Instructions and Hazard Warnings

**Caution!**

In order to avoid personal injuries and damage to property, you have to read and understand the following safety instructions and hazard warnings prior to installation and use of this interface. Keep this documentation (manual) always near the interface.

5.0.1.1 Proper Use and Intended Purpose

**Caution!**

The interface is designed for analyzing, controlling and otherwise influencing control systems and electronic control units. This includes, inter alia, bus systems like CAN, LIN, K-Line, MOST, FlexRay, Ethernet, BroadR-Reach and/or ARINC 429.

The interface may only be operated in a closed state. In particular, printed circuits must not be visible. The interface may only be operated (i) according to the instructions and descriptions of this manual; (ii) with the electric power supply designed for the interface, e.g. USB-powered power supply; and (iii) with accessories manufactured or approved by Vector.

The interface is exclusively designed for use by skilled personnel as its operation may result in serious personal injuries and damage to property. Therefore, only those persons may operate the interface who (i) have understood the possible effects of the actions which may be caused by the interface; (ii) are specifically trained in the handling with the interface, bus systems and the system intended to be influenced; and (iii) have sufficient experience in using the interface safely.

The knowledge necessary for the operation of the interface can be acquired in work-shops and internal or external seminars offered by Vector. Additional and interface specific information, such as „Known Issues“, are available in the „Vector KnowledgeBase“ on Vector’s website at www.vector.com. Please consult the „Vector KnowledgeBase“ for updated information prior to the operation of the interface.

5.0.1.2 Hazards

**Caution!**

The interface may control and/or otherwise influence the behavior of control systems and electronic control units. Serious hazards for life, body and property may arise, in particular, without limitation, by interventions in safety relevant systems (e.g. by deactivating or otherwise manipulating the engine management, steering, airbag and/or braking system) and/or if the interface is operated in public areas (e.g. public traffic, airspace). Therefore, you must always ensure that the interface is used in a safe manner. This includes, inter alia, the ability to put the system in which the interface is used into a safe state at any time (e.g. by „emergency shutdown“), in particular, without limitation, in the event of errors or hazards.

Comply with all safety standards and public regulations which are relevant for the operation of the system. Before you operate the system in public areas, it should be tested on a site which is not accessible to the public and specifically prepared for performing test drives in order to reduce hazards.


5.0.2 Disclaimer

**Caution!**

Claims based on defects and liability claims against Vector are excluded to the extent damages or errors are caused by improper use of the interface or use not according to its intended purpose. The same applies to damages or errors arising from insufficient training or lack of experience of personnel using the interface.

5.0.3 Disposal of Vector Hardware

Please handle old devices responsibly and observe the environmental laws applicable in your country. Please dispose of the Vector hardware only at the designated places and not with the household waste.



Within the European Community, the Directive on Waste Electrical and Electronic Equipment (WEEE Directive) and the Directive on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS Directive) apply.

For Germany and other EU countries, we offer free take-back of old Vector hardware.

Please carefully check the Vector hardware to be disposed of before shipping. Please remove all items that are not part of the original scope of delivery, e.g. storage media. The Vector hardware must also be free of licenses and must no longer contain any personal data. Vector does not perform any checks in this regard. Once the hardware has been shipped, it cannot be returned to you. By shipping the hardware to us, you have relinquished your rights to the hardware.

Before shipping, please register your old device via:

<https://www.vector.com/int/en/support-downloads/return-registration-for-the-disposal-of-vector-hardware/>

6 Wichtige Hinweise

In diesem Kapitel finden Sie die folgenden Informationen:

6.0.1 Sicherheits- und Gefahrenhinweise	35
6.0.2 Haftungsausschluss	37
6.0.3 Entsorgung von Vector Hardware	38

6.0.1 Sicherheits- und Gefahrenhinweise



Achtung!

Um Personen- und Sachschäden zu vermeiden, müssen Sie vor der Installation und dem Einsatz dieses Interfaces die nachfolgenden Sicherheits- und Gefahrenhinweise lesen und verstehen. Bewahren Sie diese Dokumentation (Handbuch) stets in der Nähe dieses Interfaces auf.

6.0.1.1 Sach- und bestimmungsgemäßer Gebrauch



Achtung!

Das Interface ist für die Analyse, die Steuerung sowie für die anderweitige Beeinflussung von Regelsystemen und Steuergeräten bestimmt. Das umfasst unter anderem die Bussysteme CAN, LIN, K-Line, MOST, FlexRay, Ethernet, BroadR-Reach oder ARINC 429.

Der Betrieb des Interfaces darf nur im geschlossenen Zustand erfolgen. Insbesondere dürfen keine Leiterplatten sichtbar sein. Das Interface ist entsprechend den Anweisungen und Beschreibungen dieses Handbuchs einzusetzen. Dabei darf nur die dafür vorgesehene Stromversorgung, wie z. B. USB-powered, Netzteil, und das Originalzubehör von Vector bzw. das von Vector freigegebene Zubehör verwendet werden.

Das Interface ist ausschließlich für den Einsatz durch geeignetes Personal bestimmt, da der Gebrauch dieses Interfaces zu erheblichen Personen- und Sachschäden führen kann. Deshalb dürfen nur solche Personen dieses Interface einsetzen, welche die möglichen Konsequenzen der Aktionen mit diesem Interface verstanden haben, speziell für den Umgang mit diesem Interface, den Bussystemen und dem zu beeinflussenden System geschult worden sind und ausreichende Erfahrung im sicheren Umgang mit dem Interface erlangt haben.

Die notwendigen Kenntnisse zum Einsatz dieses Interfaces können bei Vector über interne oder externe Seminare und Workshops erworben werden. Darüber hinausgehende und Interface-spezifische Informationen wie z. B. „Known Issues“ sind auf der Vector Webseite unter www.vector.com in der „Vector KnowledgeBase“ verfügbar. Bitte informieren Sie sich dort vor dem Betrieb des Interfaces über aktualisierte Hinweise.

6.0.1.2 Gefahren

**Achtung!**

Das Interface kann das Verhalten von Regelsystemen und Steuergeräten steuern und in anderweitiger Weise beeinflussen. Insbesondere durch Eingriffe in sicherheitsrelevante Bereiche (z. B. durch Deaktivierung oder sonstige Manipulation der Motorsteuerung, des Lenk-, Airbag-, oder Bremssystems) und/oder der Einsatz des Interfaces in öffentlichen Räumen (z. B. Straßenverkehr, Luftraum) können erhebliche Gefahren für Leib, Leben und Eigentum entstehen. Stellen Sie daher in jedem Fall eine gefahrfreie Verwendung sicher. Hierzu gehört unter anderem auch, dass das System, in dem das Interface eingesetzt wird, jederzeit, insbesondere bei Auftreten von Fehlern oder Gefahren, in einen sicheren Zustand geführt werden kann (z. B. durch Not-Abschaltung).

Beachten Sie alle sicherheitstechnischen Richtlinien und öffentlich-rechtlichen Vorschriften, die für den Einsatz des Systems relevant sind. Zur Verminderung von Gefahren sollte das System vor dem Einsatz in öffentlichen Räumen auf einem nicht-öffentlich zugänglichen und für Testfahrten bestimmten Gelände erprobt werden.


6.0.2 Haftungsausschluss

**Achtung!**

Soweit das Interface nicht sach- oder bestimmungsgemäß eingesetzt wird, übernimmt Vector keine Gewährleistung oder Haftung für dadurch verursachte Schäden oder Fehler. Das Gleiche gilt für Schäden oder Fehler, die auf einer mangelnden Schulung oder Erfahrung derjenigen Personen beruhen, die das Interface einsetzen.

6.0.3 Entsorgung von Vector Hardware

Bitte gehen Sie verantwortungsvoll mit Altgeräten um und beachten Sie die in Ihrem Land geltenden Umweltgesetze. Entsorgen Sie die Vector Hardware bitte nur bei den dafür vorgesehenen Stellen und nicht über den Hausmüll.



Innerhalb der Europäischen Gemeinschaft gelten die Richtlinie über Elektro- und Elektronik-Altgeräte (WEEE-Richtlinie) und die Richtlinie zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten (RoHS-Richtlinie).

Für Deutschland und andere EU-Länder bieten wir Ihnen eine kostenlose Rücknahme der alten Vector Hardware an.

Bitte überprüfen Sie die zu entsorgende Vector Hardware vor dem Versand sorgfältig. Bitte entfernen Sie alle Gegenstände, die nicht zum ursprünglichen Lieferumfang gehören, z. B. Speichermedien. Die Vector Hardware muss außerdem frei von Lizenzen sein und darf keine personenbezogenen Daten mehr enthalten. Vector führt keine Kontrollen diesbezüglich durch. Sobald die Hardware versandt wurde, kann sie nicht mehr an Sie zurück geliefert werden. Mit dem Versand der Hardware an uns haben Sie Ihre Rechte an der Hardware abgetreten. Bitte melden Sie vor dem Versand Ihr Altgerät an über:

<https://www.vector.com/de/de/support-downloads/return-registration-for-the-disposal-of-vector-hardware/>



Visit our website for:

- ▶ News
- ▶ Products
- ▶ Demo software
- ▶ Support
- ▶ Training classes
- ▶ Addresses